EVALUATING THE PERFORMANCE OF A PARTICLE COUNTING SENSOR BASED ON CONTINUOUS WAVE LII

MATTEO KAMMERER^{1,2}, FABIAN PURKL¹, KLAUS PETER GEIGLE³

¹ROBERT BOSCH GMBH, GERMANY ²UNIVERSITY OF STUTTGART, GERMANY ³GERMAN AEROSPACE CENTER, STUTTGART, GERMANY

> **University of Stuttgart** Germany

BOSCH

Performance of a Particle Counting LII Sensor Motivation

Goal: Development of an optical sensor to determine the (soot) particle number

- ► Monitoring of particle number concentrations also for the <u>sub-100 nm range</u>
- ► Creating a <u>compact & low-cost sensor</u> for measurements close to the particle source

State of the art of optical particle sensors:

- Scattering-based optical sensors: limited to particle diameters >100 nm
- Condensation particle counters & LII systems: too bulky for universal, mobile use





Performance of a Particle Counting LII Sensor Laser-Induced Incandescence

- Heating of nanoparticles to temperatures above 3000 K through absorption of optical energy emitted by a laser
- Heated particles emit broadband incandescence light, which can be captured by a photodetector

Available LII methods:

- Most LII systems rely on bulky (nanosecond) pulsed, high-power Nd:YAG lasers
- ► Pulsed LII setups cannot count <u>individual</u> soot particles
- Commercially available CW-LII device SP2(-XR)¹ provides this counting capability
- Continuous wave LII as a possible solution with the potential for a compact realization







¹ Droplet Measurement Technologies



tgart 🗎 🖪

Performance of a Particle Counting LII Sensor Sensor Demonstrator Design & Setup

Laser source: NIR laser diode (currently: λ=830 nm, P=650 mW)

▶ Beam shaping to focus the laser beam to a µm-sized spot to create a particle detection area with high power densities (up to 10 ⁷6 W/cm²)

Compact optics design

- Collinear guidance of excitation & detection light
- Intensity difference (laser & LII) requires highly efficient filter systems

Detector: Silicon photomultiplier array - SiPM

- Highly sensitive for light intensities ranging from several pW to nW
- Several hundred (parallely connected) pixels operated in Geiger mode



University of Stuttgart

Germanv

Performance of a Particle Counting LII Sensor Sensor Characterisation Setup

- ► Soot source: miniCAST 5203C
- Diluter:
 - Dekati eDiluter with variable dilution ratios
 - Dekati DI-1000
- ► Particle size selection: DMA or AAC
- LII laboratory demonstrator:
 - Easy to align, change & test components
 - Potential for compact setup
- Reference devices: CPC (Airmodus), SMPS (TSI)





- Detection limit as a key performance indicator
 → measurement capability for soot particles w/ diameters below 100 nm as a goal
- ► Difficulty of a direct determination due to sensor characteristics & soot properties

Evaluation of the sensor performance

- 1. Indirect procedure for a quick estimation and simple check of cause-effect relationships and parameter variations
- 2. Measurement of "quasi-monodisperse" particle distributions for a calculation of the sensor's size-dependent detection efficiency









Approach: Indirect ratiometrical measurement procedure for detection limit

- Measurement of particle size distribution with reference equipment (e.g. SMPS)
- Simultaneously measure LII events (#/min) with sensor demonstrator
- Cut of reference data by introducing an artificial detection limit
- Adjust artificial detection limit, until comparison between LII & reference particle concentration data match for several measurements with different CAST particle size distributions
- Assumption of size-independent detection efficiencies gives a rough approximation of sensor performance



7 Corporate Sector Research and Advance Engineering | Matteo Kammerer | 2021-06-22 © Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial properties of the sector of applications for industrial properties of the sector of th

Performance of a Particle Counting LII Sensor **Dependencies of the Sensor Performance**

- Gain sensor knowledge by evaluating influences of varying parameters:
 - Laser power (power density within focus area)
 - Lens combinations
 - Particle velocity
 - Flow orientation compared to laser beam orientation

Example: Change of laser power from 300 to 700 mW

- Initially strong decrease of the calculated figure of merit (300 to 550 mW)
- Saturation for a further increase of the laser power (density)



Figure of merit:





Corporate Sector Research and Advance Engineering | Matteo Kammerer | 2021-06-22

© Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial

Performance of a Particle Counting LII Sensor Determination of the size-dependent detection efficiency



Sharp cut-off limit does not reflect the sensor's real behaviour:

- ► Typically, a transition area with size-dependent detection efficiencies can be observed
- Geometry of the focused laser beam is reason for a size-dependent detection area



9 Corporate Sector Research and Advance Engineering | Matteo Kammerer | 2021-06-22

© Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights

University of Stuttgart



- Detection limit not as a sharp edge, but as a size-dependent detection efficiency curve
 - Cut-off diameter as the smallest detectable particle size
- ► Use of a classifier (DMA or AAC) to select a quasi-monodisperse particle size distribution



1 Corporate Sector Research and Advance Engineering | Matteo Kammerer | 2021-06-22

© Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights.

Estimation of the cut-off diameter

- Selected size: 20 nm no LII counts
 - ► Largest particle diameter of this distribution (33 nm) not detectable
- Selected size: 30 nm LII counts registered
 - ► Largest particle diameter of this distribution (58 nm) detectable

Cut-off diameter between 33 nm and 58 nm



1 Corporate Sector Research and Advance Engineering | Matteo Kammerer | 2021-06-22

© Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights



Performance of a Particle Counting LII Sensor Determination of the Particle Size

Goal:

Gain size information directly from registered LII signal shapes w/o additional device (e.g. SMPS)

- ► Dependency of the emitted LII signal to the soot particle diameter (*Q* /rad ∝*d*/P/3)
- Calculation of the distribution's mean diameter through fitting of mean data to calibration values



Performance of a Particle Counting LII Sensor Particle Counting Capability



© Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights.

BOSCH

Performance of a Particle Counting LII Sensor Conclusion & Outlook

- ► Functional sensor demonstrator for measurement of CW-LII signals of soot particles
- Influences on sensor performance investigated
- Detection efficiency curve successfully determined
- Calculation of particle mean diameters



Next steps:

- Transfer gained knowledge to a compact sensor demonstrator
- Online determination of particle size distributions



ttgart 问 BC

Performance of a Particle Counting LII Sensor Literature

- [1] Kammerer, M., Purkl, F. (2019). Poster presented at the 23rd ETH-Conference on Combustion Generated Nanoparticles, Zurich, CH.
- [2] Michelsen H.A. et al.. Laser-induced incandescence: Particulate diagnostics for combustion, atmospheric, and industrial applications. Progress in Energy and Combustion Science 51 (2015) 2–48.
- [3] Kammerer M., Purkl F., Geigle K.P. (2020). Presented at the European Aerosol Conference, Aachen (online)
- ► [4] Bertò M. et al.. (2019). Presented at the 23rd ETH-Conference on Combustion Generated Nanoparticles, Zurich, CH.



BACKUP

BOSCH

Performance of a Particle Counting LII Sensor Experimental Evaluation of LII Events

- ► LII events are registered and counted when surpassing a set threshold (voltage + duration)
 - Settings depend on the demonstrator electronics' noise level
- Typical detector events show a duration of several µs and pulse heights ranging from 15 mV to >1 V
 - Signal duration depends on the heat-up time and duration of particles propagating through laser focus (and focus geometry)
 - Intensity relates to individual particle size







Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights



► Ratiometrical method to ensure a fast assessment of the sensor performance



Introduction of an artificial lower limit $d\downarrow L$, artificial for SMPS measurements



Sum of PN concentrations starting at $d\downarrow L$, artificial



18 Corporate Sector Research and Advance Engineering | Matteo Kammerer | 2021-06-22

© Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights

► Ratiometrical method to ensure a fast assessment of the sensor performance



10 Corporate Sector Research and Advance Engineering | Matteo Kammerer | 2021-06-22

© Robert Bosch GmbH 2021. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights